



This illustration shows position of screws at points 1, 2 and 3.

INSTRUCTIONS FOR MOUNTING DIPLOMAT/PAPERSAFE RUSTPROOF RECEPTACLE

- STEP 1 Place this TEMPLATE, level, in the desired location.
- STEP 2 With TEMPLATE in position mark points 1, 2 and 3.
- STEP 3 Drill $1/8''$ diameter holes. Drive screws HALF WAY in.
- STEP 4 Place receptacle over the 3 screws, then move the receptacle downward until screws are in the narrow slots.
- STEP 5 Lift receptacle lid. Tighten top screws 1 and 2 tighten screw 3 LAST.